



Pcounter for Lexmark

Compatibility List

Pcounter Embedded for Lexmark
2018.06.06

A.N.D. Technologies
4104 24th Street #627
San Francisco, CA 94114
USA

E-Mail: support@pcounter.com

Web: <http://www.pcounter.com>

Phone: (415) 701-9222

Fax: (415) 651-9000

Copyright © 2018

Table of Contents

0.0.0 Introduction	2
0.0.1 Trial Period Information	2
1.0.0 Goal	2
1.1.0 What is Pcounter for Lexmark	2
1.2.0 Requirements.....	3
2.0.0 Unsupported Models	4
3.0.0 Supported Models 1 of 2	4
3.0.0 Supported Models 2 of 2	5
3.0.0 Documentation Links	6

0.0.0 Introduction

Pcounter for Lexmark is server software that is intended to reside on a Window server.

Pcounter for Lexmark is used to control walkup user access (**authentication**) to Lexmark MFPs as well as capture walkup usage (**accounting**) for copy, scan, and fax.

A quick technical note; MFP = Multifunction Printer, and in this instance the MFP is the Lexmark printer being configured.

0.0.1 Trial Period Information

Without a valid registration number, the Pcounter for Lexmark software runs will run with full functionality for 90 days in trial mode. During this time there are no restrictions to the software’s functionality and it can be used for testing all features. At the end of the trial period a valid registration number must be inserted, or the software will no longer function until a valid registration number is entered.

1.0.0 Goal

The goal of this document is to provide a list of supported MFP models for Pcounter Embedded for Lexmark.

1.1.0 What is Pcounter for Lexmark

Pcounter for Lexmark is Windows server software that interfaces directly with the embedded operating system inside the MFP. Pcounter for Lexmark works in combination with Pcounter for Windows.

Pcounter for Lexmark provides a point of access control (Authentication), the ability to log job based data for copy, scan, and fax (Logging), and the ability to assign page quotas or currency balances to users, debiting them for individual jobs (Accounting).

Pcounter for Lexmark combines all MFP print, copy, and scan data into a single log file managed by the Pcounter for Windows Data Server. Reporting can then be done quickly and easily for all job types using Pcounter Administrator and Pcounter Web Report.

1.2.0 Requirements

Please see our Pcounter System Requirements document at:

http://apps.pcounter.com/docs/pcounter_system_requirements.pdf

The Pcounter for Lexmark server software can be installed on Windows 2008R2 Server or any later Windows “business” operating system. Windows “Home” products that lack domain support are not recommended.

The Pcounter for Windows software (version 2.90a or later) must be previously installed, configured, and in use on the Windows print server before installing and configuring the Pcounter for Lexmark embedded management software on the server.

For more detailed information about Pcounter installation and administration please refer to the Pcounter Setup Guide and the Pcounter Documentation PDFs on the Pcounter Wiki at:

www.pcounter.com/wiki

Pcounter for Windows can be downloaded from <http://www.pcounter.com>

To download Pcounter for Lexmark please contact Pcounter support at support@pcounter.com

2.0.0 Unsupported Models

The following models are unsupported by Pcounter for Lexmark and will not function with the solution:

X644e	X772e
X646e	X782e
X646dte	X940e
X85xe	X945e
X642e	XC940
T64x+4600	XC945
X646ef	

3.0.0 Supported Models 1 of 2

If the model in question is not in the supported list and confirmation is needed please email support@pcounter.com. The following models are fully supported by Pcounter for Lexmark:

X651de	X864de	X950de
X652de	X864dhe	X952de
XS651	XS860	X952dte
XS652	XS862	X954de
X654de	XS864	X954dhe
X656de	W850n	XS950
XS654	W850dn	XS955
XS656	WS850	C950de
X658de	T656	X548dte
XS658	TS656	XS548
X738de	X746de	6500e
X736de	X748de	MS610de
X734de	X748dte	MS610dte
X738dte	XS748	M3150
XS734	C748	MS810de
XS736	CS748	M5155
XS738	X792de	M5163
X466dwe	X792dte	MS812de
X466dte	XS795	M5170
X466de	XS796	MS911de
X464de	XS796	M9155
X463de	XS798	CS510de
XS463	C792e	CS510dte
XS464	C792de	CS511
XS466	C792dte	C2132
T654	C792dhe	MX410Series
TS654	CS796	MX51x
X860de	X925de	XM1145
X862de	XS925	MX610 Series
X862dte	C925de	MX611 Series

3.0.0 Supported Models 2 of 2

XM3150

MX710 Series

XM5163

MX711 Series

XM5170

MX810 Series

XM7155

XM7155X

XM7163

XM7163X

XM7170

XM7170X

MX910de

MX911dte

MX912dxe

XM9145

XM9155

XM9165

CX410 Series

CX510 Series

XC2132

MX6500e Series

CS820 Series

C6100 Series

CX820 Series

XC6100 Series

CX825 Series

XC8100 Series

CX860 Series

CS720 Series

CS725 Series

C4100 Series

CX725 Series

XC4100 Series

CS820 Series

C6100 Series

CX820 Series

XC6100 Series

CX825 Series

XC8100 Series

CX860 Series

CS720 Series

CS725 Series

C4100 Series

CX725 Series

XC4100 Series

4.0.0 Documentation Links

Download or view this guide online at:

http://apps.pcounter.com/docs/Lexmark_Compatibility_Chart.pdf

Please also visit our Pcounter Support website at: www.pcounter.com/support

This concludes the guide. If there are any questions, please email support@pcounter.com